












# MINI Coupé E

(06/2008 - 06/2009)



## Legend

	Airbag		Bodywork reinforcements		Airbag control unit
	Gas generator		Gas pressure damper		12-Volt battery
	Belt tensioner		High-voltage components		

This overview shows the maximum vehicle equipment.




### Special features:

High-voltage system with DC voltage up to 400 Volts! Do not touch high-voltage components. For labelling characteristics and details, see reverse!

**Labelling characteristics:**

- Symbol on the engine compartment lid, roof and cap of the charging socket (tank flap).
- No exhaust system present.



**Notify the BMW fire brigade:**

+49-(0)89-382-112



**Remarks:**

**The negative terminal of the 12 Volt battery in the engine compartment must be disconnected.**

- Disconnecting the negative terminal of the 12 Volt battery automatically disables the high-voltage system.
- In the event of an accident in which the airbag is triggered, the high-voltage system is also disabled.

**Switch off the high-voltage system:**

1. Open the luggage compartment.
2. Turn the Service Disconnect counter-clockwise to the "Off" position.



**Risk of death!**

Do not touch high-voltage components.

The high-voltage battery is located under the luggage compartment trim panel.

Labelling of the high-voltage battery:



Labelling of the other high-voltage components:

